

# CABINET GLASS WASH

## GLASS WASH MACHINE DETERGENT



CODE: F40

**NON TAINTING • NON FOAMING •  
FREE RINSING • REDUCES SCALE BUILD-UP •  
CONTROLS STAINING**

### RECOMMENDED USE

All machine wash applications, glassware, crockery.

### USE FOR:

Removes stubborn stains, soiling, lipstick, tanning residues.

### DIRECTIONS FOR USE

For use in cabinet type glass and crockery washing machines.

For best results use in conjunction with **PARA GLEAM RINSE**  
(Code F06).


#### Manual Application:

Fill cabinet detergent reservoir with neat product and allow machine to mix.

#### Machine Application:

Attach pick-up tube to container and adjust dosage valve to suit.

**N.B.** Not suitable for use on Aluminium, Zinc or Alkali sensitive materials.



IN USE  
RISK LEVEL



### PACK SIZES



### HEALTH + SAFETY

**EYES:** Rinse splashes to eyes, wash with water immediately.

**PPE:** Wear protective gloves (Alkali resistant) and eye protection.

For full Health & Safety information refer to the Safety Data Sheet.



pH CONCENTRATE



PARAGON PRODUCTS (UK) LTD, EAST LOTHIAN EH21 6SY

Tel 0131 653 2222. [sales@paragononline.co.uk](mailto:sales@paragononline.co.uk)

[www.parangroup.co.uk](http://www.parangroup.co.uk)

CODE: F40 10-15

